

Oregon

| | VAPOR INTRUSION SCREENING LEVELS ($\mu\text{g}/\text{m}^3$) ^{1, 2, 3} | | | |
|----------------------------|--|--------------------------------|------------------------|----------------------------------|
| | Sub-Slab Residential | Sub-Slab Industrial/Commercial | Indoor Air Residential | Indoor Air Industrial/Commercial |
| Benzene | 72 | 1,600 | 0.36 | 1.6 |
| Tetrachloroethylene | 2,200 | 47,000 | 11 | 47 |
| Trichloroethylene | 95 | 2,900 | 0.47 | 2.9 |
| Vinyl Chloride | 33 | 2,800 | 0.17 | 2.8 |

Notes:

1. Oregon Department of Environmental Quality (DEQ) vapor intrusion screening levels are noted in the table and can be found [here](#). The term "Vapor Intrusion Screening Levels" or "VISLs" is used as a generic term for regulatory standards.
2. The United States Environmental Protection Agency's (US EPA) Vapor Intrusion Screening Levels (VISLs) link is included [here](#) for reference.
3. Site-specific evaluation or mitigation is required if the VISLs are exceeded. More information on vapor intrusion guidance can be found [here](#) ("Spreadsheet of Site-specific Risk-Based Concentrations for Individual Chemicals").